

Entry of the car registration number

- Press simultaneously the preset buttons 1 and 4 (16) (hold) and
- switch on the set.

The display shows 'Code' and then '1---'.

- Enter your code with buttons 1 to 4 (16).
- Press twice the left part of the rocker switch (19)

'Car' will be shown in the display.

- Press button 1 (16) in order to choose the digits of your registration. The following digits can be entered: A . . . Z and 0 . . . 9.

- Press button 4 (16) in order to store each digit (max. 10 digits). After each storing process a star appears instead of the respective digit.

- Press first the left, then the right part of the search tuning rocker switch. Your car registration number is now stored.

Your vehicle registration number can also be indicated in the display:

- Press preset buttons 1 and 2 (16) simultaneously (hold) and

- switch on the unit

Digit by digit your vehicle registration number appears on the display, the unit then returns to the last station that was selected.

What to do in case of repair

If the radio or vehicle was to be repaired by your dealer, which may necessitate a break in power feed, please de-activate the code number from the memory as described under previous heading.

Note: In the event of the vehicle being transferred to a new owner/operator, please ensure that the code number and/or passport is also transferred.

Mislaid or forgotten code

If your Radio Security Code is mislaid or forgotten, a code information facility is available through all Vauxhall dealers. However this service will be on a chargeable basis.

