

A1, A2, A3 Tape guides

B Erase head

C Tape contact release pin

D1 Retaining posts for upper half head cover

D2 Retaining posts for lower half head cover

E Record/playback head

F Azimuth adjustment screw

G Capstan shaft

H Capstan sleeve

J Adjustable tape guide

K Pinch wheel

L1, L2 Pressure Pads

M Take-up pin

N Pressure pad operating lever

O Crescent-shaped lever

P Pause control

R Superimpose control

S Pressure pad spring

V $\frac{1}{16}$ " free movement

W Supplementary guide pillar




Fig. 2. Head layout and tape lacing diagram