

# GRAM SETTING

FOR PLAYING

78', 45 & 33 1/3

FS

OUTPUT TRANSFORMER

FS

SW4 SHOWN FULLY ANTI-CLOCKWISE POSITION (IN RECORD POSITION)

I.E. RECORD POSITION WHEN VIEWED FROM FRONT.

- SW1 1 = RECORD, 2 = PLAY BACK, 3 = BROADCAST, 4 = GRAM
- RECORDS FROM MICROPHONE
- PLAY BACK RECORDINGS
- PLAY 78', 45s & 33 1/3

SPEAKER

MAINS TRANSFORMER

TONE CONTROL ON/OFF

RECTIFIER

1. RECORD-BIAS OSCILLATOR  
2. PLAYBACK-OUTPUT

RECORD LEVEL INDICATOR (EM 81)

OPTIONAL SHORTING LINK

BIAS OSCILLATOR COIL

